



Model Rocket RMS™ O-ring, Spacer & Insulator Guide


18/20 Model Rocket RMS



Aft O-ring
5/8" x 1/16" 014




Forward O-ring
5/8" x 3/32" 111




Aft O-ring
7/8" x 3/32" 115


24/40 Model Rocket RMS



Forward O-ring
7/8" x 1/16" 018




Delay O-ring
5/8" x 3/32" 111




Forward Insulator


24/60 Model Rocket RMS



Forward & Aft O-rings
13/16" x 1/16" 017




Delay O-ring
5/8" x 3/32" 111




Forward Insulator

24/20-40 Model Rocket RMS-R/C




Aft O-ring
7/8" x 3/32" 115




Forward Insulator
(E12-RCJ Only)


29/40-120 Model Rocket RMS



Forward & Aft O-rings
1" x 1/16" 020




Delay O-ring
5/8" x 3/32" 111




Forward Insulator

32/60-100 Model Rocket RMS-R/C



Aft O-ring
1-1/8" x 1/8" 212



Forward Insulator
(F16-RCJ Only)